

Lab0:

Introduction – brief summary and reason for project

Procedure – what steps did you actually perform and in what order

Methods – kinds of calculations, programs used, level of theory, any assumptions or approximation such as quantities varied, restraints and constraints, special program options

Results – data obtained, usually in tables and plots

Analysis – explain your result

Tinker-FFE version 8.10.1 **Results**

I downloaded from Pubchem but the structure from Cactus has tiny bit higher energy

Analyze ibuprofen before Minimization:

Analysis Types [E]

Total Potential Energy : 21.0277 Kcal/mole

Analyze ibuprofen after Minimization:

Analysis Types [E]

Total Potential Energy : 12.2922 Kcal/mole

Running spacefill (FFE-Tinker version 8.10.1) on minimized energy structure. Realized that for *Probe Radius in Angstroms (Leave blank for van der Waals Area and Volume)* this needs to be added to work for (2) and (3) below.

(1) Van der Waals Area and Volume: works WITHOUT & WITH probe radii

```
$ ~/tools/Tinker-FFE/tinker/bin/spacefill ~/tools/Tinker-FFE/NIHdownloads/ibuprofen.xyz $(echo 1
N) -k ~/tools/Tinker-FFE/NIHdownloads/ibuprofen.key # $(echo <my_in1> <my_in2> ...) does same as
stdin
```

Van der Waals Surface Area and Volume :

Total Area : 240.174 Square Angstroms

Total Volume : 232.243 Cubic Angstroms

```
$ ~/tools/Tinker-FFE/tinker/bin/spacefill ~/tools/Tinker-FFE/NIHdownloads/ibuprofen.xyz $(echo 1
1.4 N) -k ~/tools/Tinker-FFE/NIHdownloads/ibuprofen.key
```

Van der Waals Surface Area and Volume :

Total Area : 240.174 Square Angstroms

Total Volume : 232.243 Cubic Angstroms

(2) Accessible Area and Excluded Volume: works only WITH probe radii

this will ask to input the Probe Radius anyway and in FFE it just stalls at "Enter a Value for the Probe Radius [1.4 Ang] :"

```
$ ~/tools/Tinker-FFE/tinker/bin/spacefill ~/tools/Tinker-FFE/NIHdownloads/ibuprofen.xyz $(echo 2  
N) -k ~/tools/Tinker-FFE/NIHdownloads/ibuprofen.key
```

this works

```
$ ~/tools/Tinker-FFE/tinker/bin/spacefill ~/tools/Tinker-FFE/NIHdownloads/ibuprofen.xyz $(echo 2  
1.4 N) -k ~/tools/Tinker-FFE/NIHdownloads/ibuprofen.key
```

Accessible Surface Area and Excluded Volume :

Total Area : 428.639 Square Angstroms

Total Volume : 693.930 Cubic Angstroms

(3) Contact-Reentrant Area and Volume: works only WITH probe radii

this will ask to input the Probe Radius anyway and in FFE it just stalls at "Enter a Value for the Probe Radius [1.4 Ang] :"

```
$ ~/tools/Tinker-FFE/tinker/bin/spacefill ~/tools/Tinker-FFE/NIHdownloads/ibuprofen.xyz $(echo 3  
N) -k ~/tools/Tinker-FFE/NIHdownloads/ibuprofen.key
```

this works

```
$ ~/tools/Tinker-FFE/tinker/bin/spacefill ~/tools/Tinker-FFE/NIHdownloads/ibuprofen.xyz $(echo 3  
1.4 N) -k ~/tools/Tinker-FFE/NIHdownloads/ibuprofen.key
```

Contact-Reentrant Surface Area and Volume :

Total Area : 229.593 Square Angstroms

Total Volume : 238.914 Cubic Angstroms

Conclusions:

Contact-Reentrant Area much closer to VDW surface area/volume than SASA, [makes sense](#).